

Accessories List



Fr. Fender 1pcs



Fr. Wheel Tire Assy. 1Set



Charger 1pcs



L. Footpeg 1pcs



R. Footpeg 1pcs



NFC 2pcs



Fr. Wheel Spacer 2pcs



Fr. Panel 1



Strip 4pcs



Strip 2pcs



Bolts M6 14 3pcs



Washer Φ6 3pcs



Dowel Pin 2pcs



Washer Φ10 2pcs



Quick Disassembling Bolt Assy. 1Set



Tool Kit 1Set



Stem Washer 1pcs



Fr. Fork Locker 1pcs



Four-jaw sleeve 1pcs



Product Quick Guide



Fr. Wheel Installation

1. Remove the Fr. Wheel axle by inner hexagon spanner #8
2. Put the Fr. wheel spacers into the Fr. wheel axle holes on the both sides of the Fr. Wheel hub.
3. Place the front wheel on the installation position in the front fork. (Please pay attention to match the disc brake caliper)
4. Lock the Fr. wheel axle with the inner hexagon spanner #8 according its rotation identification direction. The locking torque is (10-15N.m).
5. Lock the bolt on the Fr. Fork pedestal with inner hexagon spanner #5, The locking torque is (8-10N.m).



Stem Installation

1. Put the Stem Washer into the crown.
2. Install the stem, adjust to center.
3. Install Fr. Fork Locker, use 5#spanner to tight it (torque 10-12N.m), put rubber dust cap over the bolt.
4. Lock the bolts with inner hexagon spanner #4 (torque is 7-9N.m)




Brake Installation

1. Install Fr. brake upper pump assy on the right side of handlebar, close to throttle, tight it with inner hexagon spanner #4.
2. Install Rr. brake upper pump assy on the left side of handlebar, close to dash, tight it with inner hexagon spanner #4.
3. Adjust brake position, tight it with inner hexagon spanner #4 (torque is 7-9Nm).




Fr. Extended Fender

1. Fixing the Fr. Extended Fender on the Lower Crown.
2. Insert Washer Φ6 on Bolts M6x14.
3. Tighten the Bolts by Inner Hexagon spanner #5 with locking torque 8-10N.m.



Footpeg Installation

1. Put the L & R footpegs in the installation position.
2. Lock the footpegs locking nuts and Washer Φ20 by spanner #15. Locking torque is 45-55N.m.




Cable Connection

1. Connect R.Brake Power Cut-Off Cable(2-core Red)with Throttle cable(5-core Green)
2. Connect L.Brake Power Cut-Off Cable(2-core Red)with Horn cable&Dash(9-core Black)
- 3.Tighten cable with Rubber Strip.



Fr. Panel Installation

Place Fr. Panel on the bottom of headlight, Secure it with 4 Strip.
(As Left PIC. shown) .



Tire Inflation

Inflate the tire to the proper pressure. The suggested tire pressure is (225 25kpa).



Warning:

For daily cummuting, you can use the M8 quick disassemble pin for fast battery swap. For stunt and offroad riding, the M8 quick disassemble pin must be replaced by M8 pin. (Locktorque:25-30N. m)

View of the reassembled bike

